

## 9W UV Disinfection Desktop Light - Corona Virus - 120V - UVC, Fluorescent Instruction Manual

The Larson Electronics IND-TBL-GN-UVC-9W-120V is a UV Disinfection Desktop Light which can disinfect coronavirus and bacteria found on tools, equipment and work devices. This unit offers UV-C output at a range of 200nm - 280nm (253.7nm) and comes equipped with an adjustable neck.

### Wiring/Plug

This unit is equipped with 16/3 chemical and abrasion resistant SOOW cord that is fitted with an industrial grade 5-10 plug for connection to 120V AC power.

### Mount

This desktop UV light has a stable base and contains an adjustable neck for accurate positioning of the light head.

**Voltage:** 120V, 60 Hz

**Total Watts:** 9W

**Total UV Output:** 2.4W

**Expected Lifespan:** 8,000+ Hours

**Beam Angle:** 180°

### IMPORTANT

READ CAREFULLY BEFORE INSTALLING THIS FIXTURE. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE. THE IND-TBL-GN-UVC-9W-120V MUST BE WIRED IN ACCORDANCE WITH NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES. PROPER GROUNDING IS REQUIRED FOR SAFETY.

**WE STRONGLY ENCOURAGE ONLY A LICENSED ELECTRICIAN INSTALL, OPERATE AND MAINTAIN THIS PRODUCT. IF YOU ARE NOT QUALIFIED OR UNFAMILIAR WITH ANY ASPECT OF THIS INSTRUCTION SHEET, CONSULT AN ELECTRICIAN. THERE ARE NO SERVICEABLE PARTS INSIDE.**



**WARNING:** MAKE SURE POWER IS TURNED OFF BEFORE STARTING THE INSTALLATION OR PERFORMING ANY MAINTENANCE.

**RISK OF FIRE/ELECTRIC SHOCK – DISCONNECT POWER AT BREAKER BEFORE INSTALLING OR SERVICING.**

**RISK OF PERSONAL INJURY – FIXTURE MAY BECOME UNSTABLE OR DAMAGED IF NOT INSTALLED PROPERLY.**

**RISK OF BURN – ALLOW FIXTURE TO COOL BEFORE SERVICING.**

### UV Warning

**WARNING:** ULTRAVIOLET LIGHT IS HARMFUL TO EYES AND SKIN. DO NOT STARE DIRECTLY INTO THE ULTRAVIOLET BEAM WITHOUT WEARING PROTECTIVE GEAR TO PROTECT EYES FROM LONG TERM DAMAGE. UNPLUG LAMP BEFORE SERVICING.

### NOTE

Do not touch bulb with bare hands. The oils in your skin will damage the lamp. Fingerprints will result in reduced performance and significantly reduce the lifespan of the lamp unless they are removed with alcohol.

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT [SALES@LARSONELECTRONICS.COM](mailto:SALES@LARSONELECTRONICS.COM) OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT [LARSONELECTRONICS.COM](http://LARSONELECTRONICS.COM) FOR **WARRANTY** AND **RETURN** INFORMATION.